



## Instructions

1. Use two gasket clips to hold in place during CF assemble.
2. Insert each clip in the flange's leak-check groove, as shown below. The tip of the clip should not extend over the gasket more than 1/32 inch.
3. Bolt flanges together finger-tight before removing the gasket clips.