

SNAP CONTROLLER CLEANING PROCEDURE

1. With the device disconnected from your vacuum system, **POWER ON** the **SNAP CONTROLLER**.
2. Press **FULL VAC** to fully open the vacuum valve. **POWER OFF** the device.
3. On the rear of the **SNAP CONTROLLER**, cap off the **VACUUM PUMP** port. Fill the device with ethanol through the **SYSTEM** port.
4. Once filled, cap off the **SYSTEM PORT**. Shake the device vigorously to fully coat the interior. Soak for a minimum of 30 minutes, shaking every so often.
5. Remove both caps and drain.

